

FANOX

TEMPERATURE CONTROLLER FANOX TP 731

Packaging content:

- » PID Controller.
- » Back cover.
- » Brackets.
- » Rubber outline.
- » User manual.




Thank you for purchasing this product. We suggest to read the user manual carefully before using the equipment with the purpose of getting used to its configuration and operating. Keep the manual for any after-query.

www.fanox.com


DIMENSIONS / CUTOUT

Unit: mm



WARNING

- » Make sure to tight correctly the connection terminals. If this is not done correctly mechanical failures or even fire may occur.
- » Please, do not install this equipment in locations where inflammable gases can exist, due to the possibility of explosion.
- » The life-time of the equipment depends on the way of use. If that life-time is exceeded, the probability of deterioration of the equipment increases.
- » Do not dismantle, review or repair the equipment by your own without authorization. This can cause short circuits on electrical parts, failures or fire.
- » Do not introduce metallic elements between the chips of the interior of the equipment or short circuits and fire could be produced.



CAUTION

Please read the following warnings carefully, which will allow you to use correctly the equipment:

- » Use the equipment within the specified limits for its water immersion and exposure to oil.
- » Do not use the equipment in locations exposed to vibrations or thumps. The use of the equipment in these locations can cause damages due to stress.
- » Do not use the equipment in locations exposed to dust, corrosive gases or direct sun.
- » Separate the input signal from the entrance, the cables of input signal and the equipment from noise sources or high voltage cables that generate noises.
- » Separate the equipment from static electricity sources when the equipment is used in areas where a lot of static electricity is generated (e. g. manufacture of compounds, dusts or transport of fluid material by pipes).
- » The organic solutions as well as basic or acid solutions could damage the case of the temperature controller.
- » Store it to the specified temperature. If the temperature controller has been stored under - 10 °C, keep the equipment to room temperature during a minimum of 3 hours before using it.


Please, verify the supply characteristics of the equipment. Do not connect the terminals that are not going to be used.

We propose the use of AWG 18 – 24 cables for the signal line and AWG 25 – 30 cable for the supply and exit contact relay.

SPECIFICATIONS


- Supply:** 85~265 Vac, 50/60 Hz
- Display:** Upper display (red): 4 digits 0,56" 7 segments
Lower display (green): 4 digits 0,36" 7 segments
- Input signal:** Thermocouple: J, K, B, N, R, S, T, E
RTD: PT100, JPT100
Voltage DC: 0~350 mV
Output relay (resistive) SPDT, 5A/250 Vac
Output pulse voltage (SSR) NPN, 20 mA at 12 Vdc
Analog output (max. 600...): 4~20 mA, 0~10 Vdc
SPST-NO, 3A/250 Vac (resis.)
- Output control:** 00~99 s
0~999,9 °C (°F)
Output RS485 0~999,9 s
0~3 digits
1~100
ON/OFF or PID (Autotuning)
-199,9~999,9
0000~9999
-1999~9999
± 0,3 % ± 1 digit
200 ms
EEPROM
- Alarm relay:** 00~99 s
Dwell time: 0~999,9 °C (°F)
Hysteresis: Output RS485
Communications: 0~50 °C (20~85 % HR)
Operating conditions: 0~999,9 s
Output control cycle: 0~3 digits
Decimal point: 1~100
Digital filter: ON/OFF or PID (Autotuning)
Offset input: -199,9~999,9
Fraction value: 0000~9999
Setting range: -1999~9999
Accuracy: ± 0,3 % ± 1 digit
Sampling time: 200 ms
Memory: EEPROM

FRONTAL PANEL



- ① Process value and function visualization: Red LED of 7 segments.
- ② Setting value and parameters visualization: Green LED of 7 segments.
- ③ Indication of the output control.
- ④ Indication of alarms.
- ⑤ key : Advance to an inferior level and position.
- ⑥ key : Back up to a superior level and add.
- ⑦ key : Move in a level and confirm.

PROGRAM SETTING FLOWCHART




BUTTONS EXPLANATION

The settings of the equipment are controlled by means of 3 push-buttons located in the front. First you must decide to which function you want to enter and then use the push-buttons to reach it. The push-buttons are used in the following way:

	Selection	Settings
	FORWARD	Advance to inferior level
	BACKWARD	Back up to a superior level
	OK	Move in a level


BUTTON "OK"

- 1) Allows to move in a menu.
- 2) Confirm to save the settings.



BUTTON "FORWARD"

Allows to advance from a superior level to an inferior level.




It is also used to move between the positions of the digits of a value to change.



BUTTON "BACKWARD"

Allows to back up from a inferior level to a superior one:



FUNCTION LIST

Item	Subitem	Range	Default	Description
ALE.	PoS1	-1999~9999	0	Alarm relay position 1
	HYS1	0000~9999	0	Alarm relay hysteresis 1
	dY1	00~99	00 s	Alarm relay delay 1
	d1 F1	H/L o	H1	Alarm relay direction 1
	StY1	St 1~St 8	St 1	Alarm relay style 1
		St 9		Alarm follow the action of Out 1
		St 10		Alarm follow the action of Out 2
	PoS2	-1999~9999	0	Alarm relay position 2
	HYS2	0000~9999	0	Alarm relay hysteresis 2
	dY2	00~99	00 s	Alarm relay delay 2
	d1 F2	H/L o	H1	Alarm relay direction 2
	StY2	St 1~St 8	St 1	Alarm relay style 2
SCAL		St 9		Alarm follow the action of Out 1
		St 10		Alarm follow the action of Out 2
	SV	-1999~9999	0	Set value SV
	dot	dot 0~dot 3	dot 1	Decimal point set
	SCU	-1999~9999	9999	Scale upper limit value
	SL	-1999~9999	0	Scale lower limit value
	L1 EH	-1998~9999	9999	Maximum range value SV
	L1 EL	-1999~9998	-1999	Minimum range value SV
	Unit	oC/oF	oC	Unit
	PERC	on/off	OFF	Percentage
	SCU1	000.0~100.0	100	Scale input upper limit value
	SL1	000.0~100.0	0	Scale input lower limit value
CtL	oPEF	P1 d/o on/off	ON/OFF	Operation
	tUo	tUn/oFF	OFF	Autotuning
	b1 AS	-1999~9999	0	Input setting PV
	oFSE	-1999~9999	0	SV offset value during autotuning
	P	0000~9999	3	P value
	I	0000~9999	200	I value
	D	0000~9999	20	D value
	EARF	0000~9999	0	Manual reset
	F1 Lt	1~100	1	Input digital filter
	EodE	H-C	H-C	Hold temperature over room temperature
		CoAL		Hold temperature below room temperature
	oUt 1	HEARt	HEARt	Heater is controlled by Out 1
		CoAL		Cooler is controlled by Out 1
	oUt 2	HEARt	CoAL	Heater is controlled by Out 2
		CoAL		Cooler is controlled by Out 2

Item	Subitem	Range	Default	Description
CtL	d1 F1	H1/L o	H1	Control output direct / reverse operation 1
	d1 F2	H1/L o	H1	Control output direct / reverse operation 2
	CYC1	0000~9999	5 s	Cycle time 1 (seconds)
	CYC2	0000~9999	5 s	Cycle time 2 (seconds)
	HYS1	0000~9999	0000	Control output hysteresis 1
	HYS2	0000~9999	0000	Control output hysteresis 2
	dbon	on/off	OFF	Deadband control
	dEb1	-1999~9999	0	Deadband parameter of heater
	dEb2	-1999~9999	0	Deadband parameter of cooler
	SELE	E EP	E EP	Thermocouple type K (-200~1370 °C)
		J EP		Thermocouple type J (-210~1200 °C)
		T EP		Thermocouple type T (-200~400 °C)
INP		E EP		Thermocouple type E (-200~1000 °C)
		R EP		Thermocouple type R (-50~1760 °C)
		S EP		Thermocouple type S (-50~1760 °C)
		B EP		Thermocouple type B (250~1820 °C)
		N EP		Thermocouple type N (-200~1300 °C)
		PtEP		Pt100 (-200~850 °C)
		JPtEP		JPT100 (-200~850 °C)
		DC EP		DC Type (0~350 mV)
	id	0000~0255	0001	Device ID number
	bPS	600	9600	BaudRate : 600
		1200		BaudRate : 1200
		2400		BaudRate : 2400
CoEE.		4800		BaudRate : 4800
		9600		BaudRate : 9600
		1920		BaudRate : 19200
		3840		BaudRate : 38400
	StYL	Bn1	Bn1	8 bit size; no parity; 1 stop bit
		Bn2		8 byte size; no parity; 2 stop bit
		Bp1		8 byte size; odd parity; 1 stop bit
		BE1		8 byte size; even parity; 1 stop bit
	FoFE.	HEX	HEX	Hex
		ASC		Ascii
	toUE	0100~9999	0100	Time Out / ms
	LABE	Lb00	Lb00	Lock label 0
LoCE		Lb01		Lock label 1
		Lb02		Lock label 2
		Lb03		Lock label 3

DESCRIPTION OF PARAMETERS

HYS.
Control output hysteresis

A hysteresis can be adjusted around the set point to prevent chattering.

EARF
Manual reset

In PID control, I=0, PV=SV, reset the control output to the fixed value in this section.

F1 Lt
PV input filter

This function should be used when the value of PV fluctuates widely, due to noises in the input signal. If a longer constant time is fixed, the filter eliminate more noises.

CYCL
Control output cycle time

The cycle time is the period of ON/OFF repetitions of a relay or voltage pulse output in the proportional PID control. The ratio of the ON time to the cycle time is proportional to the control output value.

d1 F
LoCE
Function list lock

Direction of relay.

You can set the mode of function lists which can be displayed and edited.

TROUBLESHOOTING

1
4
0000
UUUU

Display over scale

Display under scale

PV over scale

PV under scale

Sensor break

ALARM MODE SETTING

▲: SV ▲: Alarm setting value ▼: Hysteresis setting value

Deviation high alarm
OFF ON

Deviation high alarm
OFF ON

Deviation low alarm
ON OFF

Deviation low alarm
ON OFF

Deviation high/low alarm
ON OFF ON

Band alarm
OFF ON OFF

Process high alarm
OFF ON

Process low alarm
ON OFF

FUNCTION LOCK

LOCK	Lb03	Lb02	Lb01	Lb00
ALE.				
PoS1			0	0
HYS1				0
dY1				0
d1 F1				0
StY1				0
PoS2			0	0
HYS2				0
dY2				0
d1 F2				0
StY2				0
SCAL				
SV		0	0	0
dot				0
SCU				0
SL				0
L1 EH				0
L1 EL				0
Unit				0
PERC				0
SCU1				0
SL1				0
CtL				
oPEF			0	0

LOCK	Lb03	Lb02	Lb01	Lb00
tUn			0	0
b1 AS			0	0
oFSE			0	0
P			0	0
I			0	0
D			0	0
EARF			0	0
F1 Lt			0	0
EodE			0	0
oUt 1			0	0
oUt 2			0	0
d1 F1			0	0
d1 F2			0	0
CYC1			0	0
CYC2			0	0
HYS1			0	0
HYS2			0	0
dbon			0	0
dEb1			0	0
dEb2			0	0
INP				
E EP				0
J EP				0
T EP				0

LOCK	Lb03	Lb02	Lb01	Lb00
E EP				0
T EP				0
S EP				0
B EP				0
N EP				0
PtEP				0
JPtEP				0
DC EP				0
CoEE.				0
id				0
bPS				0
StYL				0
FoFE.				0
toUE				0
LoCE				0
LABE	0	0	0	0

FANOX ELECTRONIC
PAE. Asuaran, Edif. Artxanda, 23
48950 ERANDIO (Bizkaia) - SPAIN
Tel: +34 94 471 14 09 ; Fax: +34 94 471 05 92
www.fanox.com

HYSTERESIS

	Cal.	Enf.
SV+dEb2	X	0
SV	X	X
SV+dEb1	X	X
	0	X

dEb1 < 0 ; dEb2 > 0

	Cal.	Enf.
SV+dEb2	X	0
SV	0	0
SV+dEb1	0	0
	0	X

dEb1 > 0 ; dEb2 < 0

X: (Disable): Inhibit output.
O: (Enable): Enable control output to follow PID / ON-OFF control algorithm